






For video instructions, or instructions in other languages, please scan the QR code, or visit www.koncept.com/Guy

1



2

Place the Guy lantern onto the charging dock. Connect the USB-C cable from the dock to a USB-C charger (Not included).




Indicator light

Slowly pulsing during charging.
Stays on when 100% charged.



Power button

- Press to cycle through 0% / 20% / 50% / 100% brightness
- Press & hold to dim gradually to minimum 10%, lift finger to pause dimming at any time.
- Press control button once,
 - if battery is below 10%, indicator light flashes 3 times within 1 second.
 - if battery is above 10%, indicator light turns on for 3 seconds.

Instructions



- 3 Help Guy put on the hat.



Specifications

Guy lantern light

Model	GUY
Light Color	Soft white
Light Temperature	2700 K

Battery Disposal

Dispose of the battery in compliance with local hazardous material regulations. Do not incinerate. For proper recycling or disposal, contact your local waste authority.






Koncept Inc.
429 E. Huntington Drive
Monrovia, CA 91016, USA
Phone: 323-261-8999
Fax: 323-261-8998

Customer Support:
support@koncept.com

Web Address:
www.koncept.com

- Optional clothing items for Guy**
Simply unscrew the head off the body, place the optional clothing in between and screw together the head and body.

These optional clothing items are sold separately, check them out at our web store.



BATTERY CARE & CHARGING GUIDELINES

Your GUY lantern is powered by a rechargeable lithium-ion battery designed for long-lasting performance. As with all rechargeable batteries, its capacity will gradually decrease over time with regular use.

Charging & Daily Use

- **Recharge as Needed:** You do not need to fully discharge the battery before recharging. Regular charging is recommended to help maintain battery health.
- **Low Battery Warning:** When the battery level drops below 10%, the indicator light flashes three times when the power button is pressed. Recharge your lantern soon after seeing this warning.
- **Charging Indicator:** The indicator light slowly pulses while charging and remains steadily illuminated when fully charged.
- **Charging Equipment:** Use the supplied GUY charging dock with a compatible USB-C power adapter. For commercial applications, the optional Koncept GUY Charging Mat can charge up to six lanterns simultaneously.

Long-Term Storage

- **Avoid Storing with an Empty Battery:** If the lantern will not be used for an extended period, make sure the battery has some charge remaining before storing it.
- **Recharge Periodically:** If stored for several months, check and recharge the lantern approximately every three months to prevent the battery from becoming completely depleted.
- **Store in a Cool, Dry Place:** Keep the lantern away from direct sunlight, excessive heat, and freezing temperatures.

Safety Precautions

- Charge the lantern in a dry location at room temperature. Do not charge in freezing conditions or extreme heat.
- Keep the charging dock, charging mat, and electrical connections dry.
- Do not charge or use the lantern if it shows signs of damage, unusual overheating, or battery swelling.
- Use only compatible charging equipment and follow Koncept's charging instructions.

Please note: Battery runtime will gradually decrease with age and use. This is normal for rechargeable lithium-ion batteries and does not necessarily indicate a defective product.